Anritsu

Site Master™ and Cable Mate™ Antenna and Cable Analyzer

Battery Replacement and Disposal Guide

Battery Markings

The nickel-cadmium battery used in the Site Master and Cable Mate is covered by the Battery Directive (91/157/EEC). As such, the battery is marked as follows to indicate controlled disposal.

This marking indicates that the battery is a recyclable product.

NiCd

This marking indicates that the battery requires separate collection and shows the chemical system (Nickel/Cadmium).

Component	% of Cell Weight
Nickel	19 to 26%
Cadmium	17 to 22%

This marking indicates the heavy-metal conponent concentration as a percentage of battery cell weight.

Introduction

This guide provides a description of the battery contained in the Site Master and Cable Mate series instruments and instructions for its removal, replacement, and disposal.

Battery Description

The Site Master and Cable Mate instruments are powered by a rechargeable nickel-cadmium (NiCd) battery. The concentrations of these heavy metal components as a percentage of cell weight are as follows:

Component	% of Cell Weight *
Nickel	19 to 26%
Cadmium	17 to 22%

* Concentrations vary depending upon the state of charge or discharge.

The chemical components of the battery are packed in a hermetically-sealed cell case. The battery is housed in a cylindrical metal case with a resetting safety valve. This safety device activates to ensure safety in the case of an abnormal increase in gas pressure in the battery.

Optimal operating temperature range for battery use is –20 C to 60 C. The nickel-cadmium battery should not be used or placed in high temperature zones such as under strong direct sunlight, inside a hot vehicle, near a fire, or in front of a stove.

After use, the battery should be recharged as soon as possible. When the nickel-cadmium battery is not to be used for a long time, it should be stored in a cool place.

When spent, the nickel-cadmium battery should be replaced and recycled as described in the following paragraphs. Do ***not*** throw the battery away!

Battery Removal and Replacement

The following paragraphs provide instructions for removing and replacing the Site Master and Cable Mate battery assembly. Refer to Figure 1 during this procedure.

Battery Removal

Step 1. Place the Site Master or Cable Mate face up on the work surface.

Step 2. Remove the four corner rubber bumpers (1).

Step 3. Remove the four screws (PN 900-811) (2).

Step 4. While holding the two halves of the Site Master or Cable Mate together, turn it over and set it face down on the work surface.

CAUTION

In the next step, the Main RF PCB assembly (3) and test port panel (4) must stay with the front panel.

Step 5. Remove the bottom half (5) and fold it over to lay upside down on the work surface.

Step 6. Disconnect the battery connector from J6 (6) of the Main RF PCB assembly (3).

Step 7. Remove the four push-pull connectors (7) holding the battery bracket (8) in place and lift the bracket clear.

Step 8. Remove the battery assembly (9).



Figure 1. Battery Removal

Battery Replacement

NOTE

When replacing the battery, use all new parts provided in the replacement battery pack kit (PN ND41794).

Step 1. Install the new battery assembly (9).

Step 2. Install the battery bracket (8) and insert four new push-pull connectors (7) to hold the battery bracket in place.

Step 3. Attach the battery connector to J6 (6) on the Main RF PCB assembly (3).

Step 4. Set the bottom half in place.

Step 5. While holding the two halves together, turn the Site Master or Cable Mate over and lay it face up on the work surface.

Step 6. Install the four screws (2).

Step 7. Install the rubber bumpers (1) on all four corners of the instrument.

NOTE

Corner bumpers can only mount one way. That is, the raised-wedged area on the bumper inside (Detail A) attaches to the front cover.

Uncontrolled Disposal Dangers

There are dangers in uncontrolled disposal of spent nickel-cadmium batteries. A few of the reasons are listed here.

- Nickel-cadmium batteries when exposed to open flames or overheated beyond their normal operating temperature range may explode.
- Applying a strong shock to a nickel-cadmium battery or throwing it against anything can cause it to break up and leak fluid.
- Attempting to disassemble a nickel-cadmium battery can cause it to leak fluid, generate heat, or break up.
- Allowing a nickel-cadmium battery to become wet by exposing it to water or salt water can cause it to generate heat.
- Cadmium is classified by the US Environmental Protection Agency as a "B1" probable human carcinogen.

Battery Disposal

Spent nickel-cadmium batteries are valuable resources. Because they are reusable, do ***not*** throw them away. Arrange for proper return for recycling in your locality. If you do not have access to to proper disposal methods, return the battery to your ANRITSU service center. Service centers will dispose of the unit at no charge. ANRITSU service centers are listed in Table 1 on the following pages.

Table 1. ANRITSU Service Centers (1 of 2)

UNITED STATES
ANRITSU COMPANY
685 Jarvis Drive
Morgan Hill, CA 95037-2809
Telephone: (408) 776-8300
FAX: 408-776-1744

ANRITSU COMPANY
10 Kingsbridge Road
Fairfield, NJ 07004
Telephone: (201) 227-8999
FAX: 201-575-0092

AUSTRALIA
ANRITSU PTY. LTD.
Unit 3, 170 Foster Road
Mt Waverley, VIC 3149
Australia
Telephone: 03-9558-8177
Fax: 03-9558-8255

BRAZIL
ANRITSU ELECTRONICA LTDA.
Praia de Botafogo 440, Sala 2401
CEP 22250-040,Rio de Janeiro,RJ, Brasil
Telephone: 021-28-69-141
Fax: 021-53-71-456

CANADA
ANRITSU INSTRUMENTS LTD.
215 Stafford Road, Unit 102
Nepean, Ontario K2H 9C1
Telephone: (613) 828-4090
FAX: (613) 828-5400

CHINA
ANRITSU BEIJING SERVICE CENTER
Beijing Fortune Building
416W, 5 Dong San Huan Bei Lu
Chaoyang qu
Beijing 100004, China
Telephone: 010-501-7559
FAX: 010-501-7558

FRANCE
ANRITSU S.A
9 Avenue du Quebec
Zone de Courtaboeuf
91951 Les Ulis Cedex
Telephone: 016-44-66-546
FAX: 016-44-61-065

GERMANY
ANRITSU GmbH
Grafenberger Allee 54-56
D-40237 Dusseldorf, Germany
Telephone: 0211-67 97 60
FAX: 0211-68 33 53

INDIA
MEERA AGENCIES (P) LTD
A-23 Hauz Khas
New Delhi 110 016
Telephone: 011-685-3959
FAX: 011-686-6720

ISRAEL
TECH-CENT, LTD
Haarad St. No. 7, Ramat Haahayal
Tel-Aviv 69701
Telephone: (03) 64-78-563
FAX: (03) 64-78-334

Table 1. ANRITSU Service Centers (2 of 2)

ITALY
ANRITSU Sp.A
Rome Office
Via E. Vittorini, 129
00144 Roma EUR
Telephone: (06) 50-22-666
FAX: (06) 50-22-4252

JAPAN
ANRITSU CORPORATION
1800 Onna Atsugi-shi
Kanagawa-Prf. 243 Japan
Telephone: 0462-23-1111
FAX: 0462-25-8379

KOREA
ANRITSU KOREA (AWK)
#901 Daeo Bldg. 26-5
Yeoido Dong, Youngdeungpo
Seoul Korea 150 010
Telephone: 02-782-7156
FAX: 02-782-4590

SINGAPORE
ANRITSU (SINGAPORE) PTE LTD
3 Shenton Way #24-03
Shenton House
Singapore 0106
Telephone: 2265206
FAX: -2265207

SOUTH AFRICA
ETESCSA
1st Floor MOntrose Place
Waterfall Park
Becker Road
MIDRAND
SOUTH AFRICA
Telephone: 011-315-1366
Fax: 011-315-2175

SWEDEN
ANRITSU AB
Box 247
S-127 25 Skarholmen
Telephone: (08) 74-05-840
FAX: (08)71-09-960

TAIWAN
ANRITSU CO., LTD.
8F, No. 96, Section 3
Chien Kuo N. Road
Taipei, Taiwan, R.O.C.
Telephone: (02) 515-6050
FAX: (02) 509-5519

UNITED KINGDOM
ANRITSU LTD.
200 Capability Green
Luton, Bedfordshire
LU1 3LU, England
Telephone: 015-82-41-88-53
FAX: 015-82-31-303

NOTES

Anritsu

490 JARVIS DRIVE
MORGAN HILL, CA 95037-2809

P/N: 10580-00007
REVISION: E
PRINTED: OCTOBER 1997
COPYRIGHT 1995 ANRITSU CO.